

(9) List of spare parts

Item	HEYLO Art. No.	Description
22.	1400216	Ventilator complete
23.	1262400	Protective grille - ventilator
24.	1262403	Protective grille - exhaust side
25.	1400310	Condenser 3 μ F, 400 V
26.	1400526	Round blower insert 18 kW
27.	1400527	Round blower insert 9 kW
28.	1300300	Insulation jacket for heating insert
29.	1440016	Power contactor (40 A)
30.	1440400	Control fuse 6.3 A, 230 V
31.	1440408	Miniature unit circuit breaker
32.	1440707	Cam switch
33.	1450912	Extension housing for RT
34.	1450916	Cap for room thermostat connection
35.	1451002	Socket insert
36.	1660020	Unit base
37.	1430042	Safety temperature limiter 100 deg. C
38.	1660021	Formed handle
39.	1450281	Power cable with plug 63 A
40.	1309290	Operating hours counter
41.	1440045	Signal lamp green (operation)
42.	1440046	Signal lamp red (STB)

DE 30

